



Change Everything
but Keep The Heart

MINI
WASHINGTON

DESTINATION RV

User Manual

FLWM-3.5KG

Contents


Safety Precautions	2
Washing machine appearance	4
Installing the Washing Machine	5
Removing the shipping bolts	5
Adjusting the leveling leg	6
Fixing the cover bottom and guide-leg	7
Connecting the hose-water(in)	8
Connecting the hose drain	9
Installation requirements	10
Control panel and program description	13
Using methods of detergents and additives	17
Drum clean	18
Cleaning the water supply valve filter	19
Cleaning the enclosure	20
Storing the washing machine	21
Troubleshooting	22
Product Specifications	25
Program Control Board	26


Safety Precautions


Important Safety Symbols and Precautions. Please read this manual carefully before using the product and keep it properly.

Please read the instructions carefully and perform operation with caution and care when installing, maintaining and operating your washing machine to make the most of functions and extend the service life of the machine. We are not liable for damages resulting from improper use.

Meanings of icons and symbols in this manual:

 CAUTION: Hazards or unsafe practices that may result in personal injury or property damage.

 ATTENTION: To reduce the risk of fire, explosion or personal injury when using your washing machine, follow these basic safety precautions.

 WARNING: Hazards or unsafe practices that may result in severe personal injury, death or property damage.

Risk of fire

- ◆ Do not wash or soak any clothing stained with gasoline or other flammable, and toxic solvent, for the clothing will release flammable substance that may cause fire or explosion. Wash the clothing manually first, and ensure that all potentially flammable liquid, solid and particle traces are removed before putting it into the washing machine. Hazardous substances include acetone, alcohol, gasoline, kerosene, certain liquid household cleanser and detergent, turpentine, wax and wax remover.
- ◆ Do not use the strong acid cleanser.
- ◆ Do not put gasoline, alcohol, dry cleanser or other flammable and explosive substances into the washing machine as detergent.
- ◆ Do not overload the wall power socket or the extension cord. Otherwise, it may cause fire and electric shock.
- ◆ Never use this product together with other heating equipment at the same time.

Risk of placement

- ◆ Keep the playing children (or pets) away from the washing machine; if they are trapped in it, serious injury may occur.
- ◆ Install the washing machine in a dry and ventilated room rather than in a bathroom or a wet room.

Safety Precautions

Risk of placement

- ◆ Position the washing machine on a hard, flat and clean surface without any water or oil.
- ◆ Never place the washing machine on the other washing machines.
- ◆ This appliance is not intended for use by children, persons with physical defect, sensory handicap or mental deficiency and persons with insufficient relevant experience and knowledge unless they have been adequately supervised or guided by a responsible person and understand the potential hazards to ensure that they can use the appliance safely.

Risk of electricity


- ◆ The water supply hose will degrade over time. Check the expansion, kink, breakage, wear and tear as well as the leak of the hoses periodically, and replace them promptly when there is something wrong.
- ◆ Owing to hot water will be used in boiling wash program, risk of electrical scalding may exist. Especially make children keep off the product;
- ◆ In case of gas leak, ventilate the room immediately and do not touch the power plug.

Risk of power supply

- ◆ Please unplug the washing machine before performing maintenance, cleaning or repair. Repairs MUST only be carried out by qualified and experienced service personnel. Repairs made by inexperienced or unqualified persons may make more serious damage to the washing machine and cause personal injury.
- ◆ Always unplug the washing machine and turn off the water supply faucet after use.
- ◆ Never bend the power cord by force or place heavy thing on the power cord;
- ◆ Never touch the power cord with wet hand;
- ◆ Never connect too many electrical apparatuses on the power outlet to avoid overloading;
- ◆ Never install the washing machine close to other electrical apparatuses; never place a candle or cigarette on the washing machine;
- ◆ Never approach the washing machine soaked in water, otherwise an electric shock may occur;
- ◆ Please use a dedicated wall type AC power outlet of 220V/50Hz and not less than 10A;
- ◆ The specification of the power plug shall comply with the requirements of electricity load current. Use the 220V AC power supply alone with reliable grounding.








Washing machine appearance

Common part names and positions of the mini drum washing machine.




Accessories

Complete accessories and personalized design

BOLT-SPANE(1)	HOSE-WATER(IN)(1)	MANUAL-BOOK(1)	HOSE-DRAIN LINK(1)
			
GUIDE-LEG(4)	COVER BOTTOM(1)	CAP-FIXER(3)	
			

Installing the Washing Machine





Removing the shipping bolts



- ⚠** Three shipping bolts on the back of the machine must be dismantled before using the washing machine. Packing materials can be dangerous to children; keep all packing materials well out of the reach of children.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
 - Children shall not play with the appliance.
 - Cleaning and user maintenance shall not be made by children without supervision.
 - Children of less than 3 years should be kept away unless continuously supervised.

Installing the Washing Machine

Adjusting the leveling leg



Check if the leveling leg is level

Press two top corners in diagonal direction of the washing machine with both hands to test whether the washing machine could shake.




◆ If the floor is uneven, adjust the leveling leg of the washing machine (do not insert pieces of wood or any other objects under the leg)

◆ When you tighten the leg bolt with the wrench for fixation and adjustment, avoid movement of the leg.

Installing the Washing Machine


Fixing the cover bottom and guide-leg

1




Side lay the machine body and place the cover bottom to the bottom;

2




Align one side of the cover bottom and insert it into the groove;

3




Clip four bayonets of the cover bottom into the groove, and press the whole bottom plate into the groove.

4




Tear off the internal adhesive paper of rubber guide-leg and stick it on the leveling feet of machine;

5









Tear off the external adhesive paper, and put down the machine slowly to make the guide-leg stick to the ground.




After sticking the adhesive papers tightly, put down the machine body slowly to make four guide-legs fully stick to the ground.

Installing the Washing Machine

Connecting the hose-water(in)

<p>1</p>  <p>Dismantle the existing hose-water(in);</p>	<p>2</p>  <p>Loosen the screw B,turn it to a position with a distance of 5mm from A;</p>
<p>3</p>  <p>Tighten the hose-water(in) and the water tap connector.</p>	<p>4</p>  <p>Turn part B in the direction as shown in the figure and combine it with part A;</p>
<p>5</p>  <p>Take down the blank plug from the connector on the other end of T type hose-water(in);</p>	<p>6</p>  <p>Connect the hose-water(in) connector with the joint to make a click sound, automatic combination is completed.</p>

-  ◆ After installation, turn on the water tap to check for any leakage. The instruction for appliances connected to the water mains by detachable hose-sets supplied with the appliance are to be used and that old hose-sets should not be reused.
- ◆ Unplug the appliance and turn off the water faucet after use.
 - ◆ The new hose-sets supplied with the appliance are to be used and that old hose-sets should not be reused.

Installing the Washing Machine

Connecting the hose drain

The end of the hose drain may be positioned in three ways:

1. In a floor drain directly

We recommend that you shall use the hose drain attached to the appliance; it can be directly inserted into the floor drain with the width of the trough entry not less than 4 cm.


2. In a sink hose drain branch:

The end of the hose drain is connected to a sink hose drain branch. If the hose is too long, it cannot be forced into the washing machine, otherwise abnormal noise may occur. Note: the width of the sink entry shall not less than 4 cm.

3. Over the edge of a wash basin:

The end of the hose drain must be placed at a height of between 50 and 90 cm from the ground. To avoid restricting the water flow due to the bending of the hose drain, secure the hose drain over the edge of the wash basin with a hook to prevent the hose from moving.

Note: the end of the hose drain cannot be submerged in water.



Installation requirements

All electrical circuit and grounding must be set as per the national electrical standard.

Power supply

- ◆ To avoid the unnecessary risk of fire, electric shock or personal injury, all electrical circuit and grounding must be set as per the national electrical standard. It is the owner's responsibility to provide proper maintenance on the electrical appliance.
- ◆ Do not overload the wall power socket or the extension cord. Otherwise, it may cause fire and electric shock.
- ◆ Only the power cord equipped with the washing machine can be used.
- ◆ When ready for installation, ensure the power supply complies with the following items: Fuse or breaker of 220V, 50Hz, 10A. When the heating function is used, the maximum current of the washing machine may reach 10A. Ensure that your power supply unit (current, voltage and cable) can meet the normal load requirements of the appliance. Use the State Grid. If you are not sure about the voltage, contact with the manufacturer, product and service agent or qualified person.
- ◆ To guarantee your safety, use the three-core socket and check to ensure it is grounded accurately and reliably. (The washing machine has been equipped with a three-core socket.)
- ◆ Protect the power cord.
- ◆ The power cord has to be positioned so that it will not be stepped on, pressed or clamped by the article on or next to it. Pay special attention to the power cord of plug, socket and power cord contact of the appliance.


Water supply

- ◆ The working water pressure of the washing machine is 0.05MPa~0.8MPa. When the water pressure is below 0.05MPa, the water supply valve may not work normally, or the time of water supply is longer than that of program control, and the display screen shows "SF".
- ◆ The water supply tap must be less than 122cm away from the rear of the washing machine so that the water supply hose can be easily connected to the washing machine and the water tap.
- ◆ To prevent the risk of water leakage and waterway damage, consider the following ways:
 - Ensure water tap is at a reasonable position for easy connection.
 - Turn off the water tap when the washing machine is not used.
 - Check water leakage conditions of the internal loop regularly.

Installation requirements

Grounding ⚠

- ◆ The washing machine must be grounded. If the washing machine has a fault or cannot run normally, the current can be conducted to the ground, minimizing the risk of electric shock.
- ◆ The ground wire cannot be connected to the plastic pipe, gas conduit or hot-water pipeline. If the ground wire is connected to the improper ground conductor, electric shock may occur.
- ◆ If you are not sure whether the washing machine is grounded accurately, check and verification should be performed by the manufacturer, product and service agent or qualified person.
- ◆ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. The plug attached to the washing machine cannot be transformed. If the plug cannot match the socket, a suited one should be installed by the manufacturer, product and service agent or qualified person.



Ground location ⚠

To minimize the vibration or unbalanced load, the wood floor has to be reinforced. The carpet and the soft floor tile surface may cause vibration and slight movement of the washing machine in operation.



Before you install the washing machine, select a location with the following characteristics:

- ◆ Do not position the washing machine on a platform or a structure with weak support.
- ◆ A hard, level surface (if the surface is uneven, see “Adjusting the leveling leg”).

Installation requirements

Ground location

- ◆ Avoid direct sunlight, with adequate ventilation. (The washing machine shall not be installed in a bathroom or a wet room.)
- ◆ Room temperature shall not fall below 0 °C.
- ◆ Keep away from heat sources such as coal or gas stove.



Ensure that the washing machine does not stand on its power cord. Ventilation openings must not be obstructed by carpeting when the washing machine is installed on a carpeted floor.

Control panel and program description

Control panel and program description facilitate easy operation of the drum washing machine.



Boiling wash button

This button is for washing routine clothing, such as children clothing and underclothes; the boiling wash function is applicable for standard wash and baby care program only.



Course button

Press this program button to select the program required.



Start/Pause

Press this button to start/pause the operation of the machine; if you want to change washing program, press this button for pause, then press the button of selected program to start.



ON/OFF button

Turn on/ off the washing machine by this button. If the washing machine is kept unused for 10 minutes after power on, the power supply will be shut off automatically.



Display button

Display the remaining time required to complete the program. Error code is displayed if the washing machine malfunctions.

Control panel and program description

Program	Description	Temperature
Standard	Suitable for daily mixed washing of cotton, linen and chemical fiber clothing. The Standard program is for a normally soiled cotton load at rated capacity. Standard is the recommended washing program of choice for users.	95 °C *
		40 °C
Baby Care	Detergents on baby' s laundry can be dissolved completely at high temperature so that baby' s soft skin can be protected.	95 °C *
		60 °C
Quick Wash	Suitable for washing slightly soiled laundry that is worn only once or needs washing a little, has a special smell. Washing loading can not be over 1.0kg.	Cold
Soft	Suitable for washing generally or slightly soiled cotton textiles, linen bed sheet, linen table cloth, underwear, towels, shirts, etc.	30 °C
Intensive	Suitable for washing moderately or heavily soiled cotton textiles, linen bed sheet and table cloth, underwear, towels, jeans, overalls, etc.	40 °C
Rinse	Suitable for clothing that only needs rinsing or to be rinsed once more by using fabric softener.	—
Spin	Perform the spin cycle only and spin dry excess water from the clothes.	—
Drum clean	This program is designed to clean the inner drum of washing machine to keep it sanitized(no clothing shall be added when this program is used).	70 °C



* Only standard and baby care programs can choose the boiling function, other programs are not optional, and the boiling temperature is 95 °C.


Control panel and program description


Boiling wash

Eradicating invisible residual bacteria, facilitating comprehensive protection for health.

Application method of boiling wash function


- Put clothing into the washing drum and add a proper amount of detergent, then close the door;
- Press the power supply button  ;
- Press the “course” button to select standard wash or baby care program;
- Then press the “boiling wash” button;
- Press the “start/pause” button  to begin wash.



-  In order to enhance the washing effect, detergent and bleacher may be added into the washing drum before adding clothing.

Inspection before carrying out boiling wash program

- Carry out classification based on color and smudginess degree of clothing (for instance, more dirty clothing, unfaded clothing, white clothing, soft clothing etc.).
- Fasten all attached articles of the clothing and empty the pockets; if there is damage of clothing, please repair it before washing.

-  - Never boiling wash the clothing which may fade;
- Never boiling wash soft clothing, such as wool product or ladies underwear etc;

B.Check the cover of machine door

- Check if machine button is fastened;
- If clothing is clamped by the cover of machine door during wash, the clothing may be torn or leakage may occur. Please ensure machine door is closed and clothing is not clamped.

Control panel and program description



Boiling wash program Precautions


- ◆ Please use a dedicated wall type AC power outlet of 220V/50Hz and 10A;
- ◆ Never use power extension line;
- ◆ Adopting other supply voltage or current may result in fire, electric shock or power failure;
- ◆ Never use this product together with other heating equipment at the same time;
- ◆ The temperature of boiling wash program may be different due to environment;
- ◆ The internal temperature may be very high in the boiling wash program, so operate carefully to avoid scalding.
- ◆ Provide cold water to cool the hot water, ensure to reach the safe water temperature during drainage;
- ◆ Time required for sterilization by boiling wash program is based on water inlet temperature, the lower water inlet temperature is, the longer time is required;
- ◆ With specific design for the washing machine, only cold water will be supplied to cool the hot water after the boiling wash program;
- ◆ Boiling wash program can be kept on only after the machine door is closed;

Using methods of detergents and additives

Please ensure the cap-drawer is placed at the correct position, and it cannot be taken down during wash

Cap-drawer

Addition level of laundry liquid should not exceed MAX base line marked on the cap-drawer, Laundry power or laundry beads should be added into drum directly.



Precautions for using the detergent



A. Determining the amount of laundry liquid

The amount of detergent is based on the water hardness in your area and the detergent manufacturer's recommendations on the package as well as the weight of laundry, the type of fabric, the degree of soiling etc.

B. Selecting proper laundry liquid



The type of detergent you should use is based on the type of fabric (cotton, delicate items, chemical fiber and wool), color, wash temperature, degree and type of soiling. Always use "low foam" washing powder, which is designed for front loading washing machine.


- ◆ Keep detergents and additives in a safe, dry place out of the reach of children.
- ◆ Please use appropriate amount of detergent according to the type of fabric and the degree of soiling for the sake of environmental protection.
- ◆ Appropriate amount of detergent shall be used according to the weight of laundry, the degree of soiling and product description.

Drum clean

This is a drum auto clean program and can remove possibility of mould that may be present in the drum.

Precautions for using drum cleaning function

- A. Turn on the water tap.
- B. Press the Power button  to start the washing machine.
- C. Press the Program button to select the Drum clean program.
- D. Press Start/Pause button  to start the Drum clean program.



 Never add clothing into the inner drum in drum cleaning program.







Application method of drum cleaning function



- ◆ Be sure to use the specialized cleansers to clean the inner drum.
- ◆ The drum can be cleaned without cleansers for the Drum clean program.
- ◆ The Drum clean program cannot be used when there are clothes in the washing machine, or the laundry or machine may be damaged.
- ◆ Only one tenth of drum cleanser amount recommended by the manufacturer shall be used for the sake of environmental protection.
- ◆ Bleach containing chlorine may fade the laundry; be sure to use oxygen bleach only.
- ◆ There are powder and liquid cleansers to clean the drum.
- ◆ Powder cleanser: Please use powder bleach or the cleanser specialized for the inner drum of the washing machine.
- ◆ Liquid cleanser: Please use liquid oxygen bleach or the cleanser specialized for the inner drum of the washing machine.
- ◆ Never use foam type detergent.

Cleaning the water supply valve filter

You should clean the supply valve filter at least 3 to 4 times per year, or when you see “SF” error message on the display:





<p>1</p>  <p>Pull out the power plug and turn off the water supply tap of the washing machine.</p>	<p>2</p>  <p>Unscrew the water supply hose from the back of the machine.</p>
<p>3</p>  <p>With a pair of pliers, gently pull out the water supply valve filter and rinse it under water until clean.</p>	<p>4</p>  <p>Clean the inside and outside of the threaded connector.</p>
<p>5</p>  <p>Push the filter back into the original place. Reconnect the water supply hose.</p>	<p>6</p>  <p>Turn on the tap and make sure the connections are watertight.</p>

Cleaning the water supply valve filter

- Rust : Rusting may occur if water with rust or rusty article, such as hair pin, is put into the drum, or water has been remained in the drum for too long.
- Rust cleaning: Squeeze out the rust removing paste on a soft cloth or sponge, and then wipe the rusty parts.
※ Never use a steel brush, otherwise the drum will be damaged.
- Residual detergent: (Dark color and stain) After long service of the washing machine, if excessive detergent is added, or cleaning program is repeated with detergent not dissolved completely, clothing may be contaminated by residual detergent.

Cleaning the enclosure

Clean the housing of washing machine regularly to keep it clean and sanitized.

<p>1</p>  <p>1. Unplug the washing machine before cleaning, otherwise electric shock or personal injury may occur.</p>	<p>2</p>  <p>2. Never spill water on the washing machine, otherwise short circuit or electric shock may occur.</p>
<p>3</p>  <p>3. Use a wet cloth to clean the washing machine.</p>	<p>4</p>  <p>4. Never use synthetic detergent, benzene contained detergent or diluents.</p>

Cleaning the enclosure




Precautions for cleaning housing of the washing machine


- ◆ Wipe the washing machine enclosure, including the control panel, with a soft cloth and nonabrasive household detergents.
- ◆ Use a soft cloth to dry the enclosure.
- ◆ Do not pour water on the enclosure in case parts of the machine would be damaged.

Storing the washing machine


Drain the residual water out of the machine; otherwise the washing machine may be damaged.



1. Select the Spin program to drain the water out with the fastest speed.



2. Turn off the water tap and separate the water supply hose.



3. Unplug the washing machine and open the machine door to allow ventilation.

Troubleshooting

Problems and solutions

Phenomenon	Solution
Detergent remains in the detergent drawer after the washing is complete	<ul style="list-style-type: none"> ◆ Check if the water pressure is sufficient when washing. ◆ Check if the washing powder are damp and caking.
Washing machine vibrates or is too noisy	<ul style="list-style-type: none"> ◆ Check if the washing machine is set on an uneven surface. If the surface is uneven, adjust the leveling leg to level the appliance. ◆ Check if the shipping bolts are removed. ◆ Check if the washing machine is touching any other objects. ◆ Check if the laundry load is balanced in the inner drum of the washing machine.
The displayed washing time deviates from the actual washing time	<ul style="list-style-type: none"> ◆ Time deviation is due to the laundry weight, water supply and balancing time.'
The drainage pump has abnormal noise	<ul style="list-style-type: none"> ◆ Check if the drainage pump filter is blocked by laundry flocks and clean the debris.
Foam overflows from the air return hole on the back of washing machine	<ul style="list-style-type: none"> ◆ Too much washing powder, so reduce its amount; ◆ Pour the washing powder into the drum directly; ◆ Use low foam washing powder or liquid detergent dedicated for drum.

Troubleshooting

Error messages description

Error code	Code description	Solution
dF	Abnormal door lock	<ul style="list-style-type: none"> ◆ Check if the door is opened and make sure the door is closed firmly. ◆ Check if the wiring harness of the computer board was accidentally disconnected. ◆ Check if the plug wire of door switch is loose or has a poor contact.
SF	Abnormal water supply	<ul style="list-style-type: none"> ◆ Check if the water tap is turned on. ◆ Clean the water supply valve filter. ◆ Check the water pressure. ◆ Check if the drain valve is plugged up.
_F	Abnormal draining	<ul style="list-style-type: none"> ◆ Clean the drain valve. ◆ Check if the drain hose is properly installed. ◆ Check if the hose drain is plugged up.
UF	Imbalance alarm	<ul style="list-style-type: none"> ◆ Excessive eccentricity or winding of clothing, so put the clothing again after tidying up. ◆ Increase the quantity of clothing to be washed. ◆ Check if the washing machine feet are level adjusted.
CF	Abnormal communication between PCB and frequency conversion board	<ul style="list-style-type: none"> ◆ Power off the machine to check if the wire connecting the motor and the electric reactor falls off. ◆ Check if the patch cord of the motor and cables was accidentally disconnected. ◆ Check if the PCB wirings fall off.
EF	Temperature sensor abnormality	<ul style="list-style-type: none"> ◆ Check if the temperature sensor wire is in poor contact. ◆ Test the resistance of temperature sensor in cold state with the multimeter and check if it is above 1.5M Ω. ◆ Check if the wire and plug-in between the temperature sensor and the PCB are in poor contact.

Troubleshooting

Error code	Code description	Solution
EF	Too high water level	<ul style="list-style-type: none"> ◆ Disentangle flexible pipes of the pressure switch, then test-run the machine. ◆ Check if there is something wrong with the drainage pump. ◆ Check if the hose of pressure switch is clogged.
HU LU	Abnormal voltage	<ul style="list-style-type: none"> ◆ Power supply voltage is unstable. ◆ Program will run automatically after the voltage becomes stable. ◆ Purchase a device which can provide stabilized voltage.
3C	Abnormal speed caused by overload and clothing winding	<ul style="list-style-type: none"> ◆ Check if the temperature sensor wire is in poor contact. ◆ Test the resistance of temperature sensor in cold state with the multimeter and check if it is above 1.5MΩ. ◆ Check if the wire and plug-in between the temperature sensor and the PCB are in poor contact.
PF	Water level sensor abnormality	<ul style="list-style-type: none"> ◆ Check if the plug wire of the water level sensor is in poor contact. ◆ Check whether the connection of PC Board wiring harness is abnormal. ◆ Please hold using and contact after-sales service department.

Problems and solutions

A. Your washing machine is installed with the fuzzy logic control system which can automatically detect the balance of laundry during spinning. When the laundry is detected unbalanced or with strong eccentricity by the washing machine, the machine will properly extend the spin time to adjust the balance of the laundry or run at a lower speed when spinning in order to avoid damage to the machine.

B. When there are excessive foams, the time on the display will stop while the machine eliminates the foam and the machine will automatically return to normal program when finished.

C. Before contacting National Customer Service Team:

- ◆ Try to solve the problem (see “Troubleshooting”).
- ◆ Restart the program to see if the fault still exists.
- ◆ If the fault persists, call after-sales service and describe the problem.


Product Specifications

FLWM-3.5KG		
Type	FRONT LOADING WASHING MACHINE	
Rated voltage and frequency	220-240V/50Hz	
Wash mode	Drum-type	
Spin mode	Centrifugal type	
Rated wash and Spin capacity	Wash	3.5kg
	Spin	3.5kg
Water heating power (W)	1100W	
Rated Heating Washing Power	1300W	
Tap water pressure(MPa)	0.05MPa-0.8MPa	
External dimensions (mm)	500×415×630	
Net weight (kg)	34kg	
Rotation rate of wash	50RPM	
Rotation rate of spin	700RPM	

Enter into the energy efficiency test program:

Within 15 seconds of starting up, select the Intensive program and press the Boiling wash button five times in five seconds.

Program Control Board



说明书尺寸：145*210mm

净重：48g

材质：

封面：157g双面铜版纸，内页：70g 普通纸

2023. 10. 8

第23. 24故障代码修改，第25页能效检测方式修改，第26页电路图修改
其他几页单词修改

2024. 3. 13

第14页程序增加温度描述